

# LifeSize Remote Control

## Selecting a screen layout



Press to swap what is shown on the screen.

## Go back



Press to go back one screen.

## Return to main screen



Press to go back to the home screen.

## Navigation buttons



Navigation panel buttons change function depending upon what is on the screen.


## Ending call



Press to end a two-way call. Press twice to end a multiple way call.



## Selecting a camera to control



Press to switch between the near and far cameras in a call.

## Adjusting (Pan Tilt Zoom) Camera



Press to select a camera to control.



Use the arrow keys to pan left and right, tilt up and down.



Press (+) to zoom in. Press (-) to zoom out.

zoom

## Adjusting Sound



Press (+) to increase volume. Press (-) to decrease volume.

volume



Press to mute or unmute the audio.

mute

## Change Input



Press input to change primary and presentation inputs.

input